

# **TROUBLESHOOTING**

## **PROBLEMS**

Flow of gas seems abnormal

- Check that gas cylinder is not empty.
- Burner holes are dirty and clogged.
- Gas regulator is not working.

Smell of gas

- Gas valve is open.
- Gas hose is leaking (check with soapy water).
- Gas hose is bent or damaged or not positioned properly

Oven does not heat up

- Gas valve is not open.
- Oven knobs not opened properly.
- Oven fire has blown out (for gas oven).
- Power supply is not switched on (for electric oven).

Cooker smokes

- Burning of oils and fats left behind (oils & fats must be cleared off from oven after cooking).

